

# BEFORE YOU BEGIN

Before you begin installation, please ensure you received all items listed below.

- Essential Acoustic Polyester Blades
- Suspension Cables (Optional) (2 per blade)

## Hardware and Tools Needed

- Ceiling Loops (2 per blade). These can be various types such as screw hooks to a joist or twist clips that attach to a suspended ceiling frame.
- Cable Cutter
- Ruler or tape measure
- 2.5mm hex wrench if clevis hardware

## Mounting Method: Hanging Hardware

### Essential Acoustic Polyester Blade Preparation

- Carefully remove acoustic blades from the packaging.
- Lay each PET blade flat on a clean, dry and even surface such as a floor or a table.

### Application:

1. Ensure proper blade preparation as noted above.
2. Attach ceiling loops to the ceiling. Spacing should be 46 inches apart.
3. Attach one end of the wires to the blade mounting holes. If using a U-shaped clevis attachment, use the hex wrench to partially remove the screws. Place the clevis over the mounting hole of the blade and turn the screw into the hole so that the cable is attached to the blade.
4. Both ends of the cable can be adjusted. Slide the cable through the hardware until measurement indicates the desired length between hardware ends. Cut off excess cable length leaving a few extra inches for adjustments.
5. Attach the cable hooks to the ceiling loops so that the blade is held above the floor.
6. Using a level, adjust cable length so the blade hangs evenly. Once level, trim any excess cable.

If you are missing any required items from your order, contact us at: <https://acousticsamerica.com/orderissue> or call us at 1-800-569-4907.