


## BEFORE YOU BEGIN

Please check to ensure you have all of the below items before you begin installation of your product.

- Acoustical Clouds (quantities and sizes based on your order.)
- Mounting Hardware (Rotofast Included with order. Quantities vary based on size of cloud.)

	Number of Anchors (Based on Panel Size)							4 Anchors
	24" x 24"	36" x 24"	36" x 36"	48" x 12"	48" x 24"	48" x 36"	48" x 48"	
	60" x 24"	60" x 36"	60" x 48"					
	72" x 24"	72" x 36"	72" x 48"	96" x 24"	96" x 36"			
	96" x 48"	120" x 24"	120" x 36"	120" x 48"				8 Anchors

**Note:** Adjustable ceiling cloud hanging wire and ceiling-side attachment hardware are not included.

IF YOU ARE MISSING ANY REQUIRED ITEMS FROM YOUR ORDER,  
PLEASE CONTACT US ONLINE [HERE](#).

---

---

# Mounting Method: Rotofast Cloud Anchor


## STEP 1

Secure the ceiling mount eye hooks (or alternative mounting hardware as specified) into the ceiling substrate.




## STEP 2

Secure suspension wire to the cloud anchors (located on the back of the acoustic cloud) and to the hardware installed in the ceiling substrate.





See [Appendix A](#) for suggested Rotofast install locations based on your cloud size.






## Appendix A: Rotofast Anchor Locations






## Appendix A: Rotofast Anchor Locations






## Appendix A: Rotofast Anchor Locations



## Appendix A: Rotofast Anchor Locations



## Appendix A: Rotofast Anchor Locations



## Appendix A: Rotofast Anchor Locations

