

BEFORE YOU BEGIN

Please check to ensure you have all of the below items before you begin installation of your product.


Items Supplied by Acoustics America

Check that the quantities, colors and sizes of baffles received match your order receipt.

Note: These instructions apply to waffle clouds with either square or radiused ends.



- **(2) Main Support Pieces**
Each main support piece has 4 short slots and 2 mounting holes.
- **(4) Cross Pieces**
Each cross piece has 2 long & 2 short slots.
- **(2) Grid Pieces**
Each grid piece has 4 long slots.





Hanging Hardware: based on your option selection.

If you are missing any required items from your order,
contact us at: <https://acousticsamerica.com/orderissue> or call us at **1-800-569-4907**.

STEP 1


Set the Main Supports on edge with the slots up, and place the first Cross Piece as shown. Add the three remaining Cross Pieces.

Note: There is no need for glue or other attachments, as each piece is supported by the others and held by gravity.



STEP 2

Place the two Grid Pieces across the middle of the Cross Pieces to complete the 4x4 grid.



STEP 3

Insert 4 hooks in the mounting holes at the top of the main supports.

STEP 4

Attach the other ends of the mounting wires to the ceiling. This will vary depending on the type of ceiling attachment.

STEP 5

Adjust the mounting wires so the grid is level at the desired height. To shorten the height, pull the wire through the product end. The lock feature will automatically engage. To lengthen the height, depress the auto lock feature at the base of the product end, slide to the desired position, being careful not to remove the hardware from the wire. If this happens, feed the wire back through the hardware.

- 1. Level the Grid:** Adjust the mounting wires so the grid is level at the desired height.
- 2. Shorten the Height:** Pull the wire through the product end to shorten the height. The lock feature will automatically engage.
- 3. Lengthen the Height:**
 - Depress the auto lock feature at the base of the product end.
 - Slide the product hardware to the desired position, being careful not to remove the hardware from the wire.
 - If the hardware is removed, feed the wire back through the hardware.

