



BEFORE YOU BEGIN

Please check to ensure you have all of the below items before you begin installation of your product.

Items Supplied by Acoustics America

- Essential Acoustics Hanging Divider(s)
- Suspension cables (sold separately, 2 per divider)
- 6 Clips (Modular version only)

Hardware and Tools Needed

- Ceiling side attachment options (2 per divider). These can be various types such as our cable pellet and screw to drywall or beam; screw-in eye hooks (not included), or clip-on drop grid eye hooks (sold separately).
- Cable cutter
- Ruler or tape measure
- 2.5mm hex wrench (if clevis hardware)

If you are missing any required items from your order,
contact us at: <https://acousticsamerica.com/orderissue> or call us at **1-800-569-4907**.



Hanging Divider(s) Preparation:

- Carefully remove hanging divider(s) from the packaging.
- Lay the divider flat on a clean, dry and even surface such as a floor or a table.



Application:

1. Ensure proper divider preparation as noted above.
2. Attach ceiling loops to the ceiling. Spacing should be 24 inches apart.
3. Attach one end of the wires to the divider mounting holes. If using a U-shaped clevis attachment, use the hex wrench to partially remove the screws. Place the clevis over the mounting hole of the divider and turn the screw into the hole so that the cable is attached to the divider.
4. Both ends of the cable can be adjusted. Slide the cable through the hardware until measurement indicates the desired length between hardware ends. Cut off excess cable length leaving a few extra inches for adjustments.
5. Attach the cable hooks to the ceiling loops so that the divider is held above the floor.
6. Using a level, adjust cable length so hanging divider hangs evenly. Once level, trim any excess cable.

If you are missing any required items from your order,
contact us at: <https://acousticsamerica.com/orderissue> or call us at **1-800-569-4907**.


Hanging Divider(s) Preparation:

- Carefully remove hanging divider(s) from the packaging.
- Lay the panel sequence flat on a clean, dry and even surface such as a floor or a table.
- Pull the two sides of the ring clip apart by hand.
- Insert the ring clip into the bottom holes of the 1st panel, then through the top holes of the subsequent panel.
- Push the two sides of the ring clip together until it clicks and locks shut.
- Repeat steps for next 2 panels.



Application:

1. Ensure proper divider preparation as noted above.
2. Attach ceiling loops to the ceiling. Spacing should be 24 inches apart.
3. Attach one end of the wires to the divider mounting holes. If using a U-shaped clevis attachment, use the hex wrench to partially remove the screws. Place the clevis over the mounting hole of the divider and turn the screw into the hole so that the cable is attached to the divider.
4. Both ends of the cable can be adjusted. Slide the cable through the hardware until measurement indicates the desired length between hardware ends. Cut off excess cable length leaving a few extra inches for adjustments.
5. Attach the cable hooks to the ceiling loops so that the divider is held above the floor.
6. Using a level, adjust cable length so hanging divider hangs evenly. Once level, trim any excess cable.



If you are missing any required items from your order,
contact us at: <https://acousticsamerica.com/orderissue> or call us at **1-800-569-4907**.